

NOTES:

- WHEN POSSIBLE, MM6125 SHOULD BE APPLIED UNDER PENETRATION BASE PLATE.
- PENETRATION SURFACE MUST BE CLEAN AND FREE OF ALL RUST AND OTHER CONTAMINANTS, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125.
- IN COVERED/BURIED CONDITIONS, THE FLASHING DETAIL SHOULD EXTENDED AS HIGH AS POSSIBLE. FLASHING MUST BE TERMINATED AT OR ABOVE OVERBURDEN LEVEL AND NO LESS THAN 8" ABOVE SUBSTRATE.
- 4. USE LARGEST SHEETS OF UNCURED NEOPRENE POSSIBLE, WHEN POSSIBLE, HOLES/SLITS SMALLER THAN THE PENETRATION SHOULD BE CUT IN THE CENTER OF THE SHEET OF NEOPRENE AND THE SHEET PULLED DOWN OVER THE PENETRATION.
- CUT A SLIT OR "X" INTO THE NEOPRENE SHEET DIRECTLY OVER THE BOLT HEADS TO ALLOW EMBEDDING/FORMING TIGHTLY AROUND BOLT HEAD.
- 6. HYDROSEAL RESIN SHOULD BE APPLIED DIRECTLY OVER PRIMED MM6125



IRREGULAR SHAPE PENETRATION WITH BASE PLATE

SCALE: NONE DATE: 11/16/22

R-10B