



NOTES:

1. AREA AROUND DRAIN SHOULD BE DEPRESSED/SUMPED TO PROMOTE POSITIVE WATER DRAINAGE.
2. REINFORCEMENT SHALL BE ONE SHEET OF FLEX-FLASH UN EXTENDING A MINIMUM OF 6" BEYOND THE DRAIN FLANGE ON ALL SIDES AND SECURED IN CLAMPING RING AT DRAIN.
3. ALL DRAINS ARE REQUIRED TO HAVE FLASHING CLAMPING RING ASSEMBLIES. CONSULT SPECIFIC DRAIN MANUFACTURER FOR ADDL. ACCESSORIES (i.e., DEBRIS SCREENS, LOW-PROFILE DOMES, EXTENSIONS, ETC.)
4. APPROVED PROTECTION LAYER SHOULD NOT BE EXTENDED UNDER THE CLAMPING RING OF THE DRAIN. FLEX-FLASH F SHOULD STOP A MIN. OF 4" AWAY FROM THE DRAIN.



**Monolithic
Membrane
6125-FR**
ROOFING SYSTEMS

AMERICAN HYDROTECH, INC.

TYPICAL DRAIN DETAILS

SCALE: NONE
DATE: 12/01/17

R-8B