

## NOTES:

- 1. BENT SHEET METAL CORNER MUST BE OF SUFFICIENT GAUGE AND SECURED TO THE DECK AND WALL SUFFICIENTLY TO PREVENT BUCKLING.
- 2. FLEX-FLASH UN MUST BE USED TO REINFORCE MM6125 OVER THE BENT METAL CORNER.
- 3. METAL SUBSTRATE REQUIRE ROUGHENING/SANDING, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125. ALSO, IT MUST BE FREE OF ALL OIL AND RUST.
- 4. HYDROSEAL RESIN MUST EXTEND 4" MIN. ONTO THE APPROVED SUBSTRATE BEYOND THE MM6125 TERMINATION.



TYPICAL PARAPET AT PRECAST WALL

SCALE: NONE DATE: 10/24/19

**R-11D**