

- TREATED WOOD BLOCKING.
- REFERENCE GUIDELINE DETAIL R-12 FOR ALTERNATE CORNER TRANSITION DETAILS, TIE-IN WITH MM6125-FR (FABRIC REINFORCED) MEMBRANE AND FLASHING WITH FLEX-FLASH MB.
- HYDROSEAL RESIN MUST EXTEND 4" MIN. ONTO THE APPROVED SUBSTRATE BEYOND THE MM6125 TERMINATION.



TYPICAL PARAPET AT PRECAST WALL

SCALE: NONE DATE: 06/01/19

R-11E