



**NOTES:**

1. THE METAL SLEEVE SHOULD BE INSTALLED IN ONE PIECE OR COMPLETELY WELDED SHUT TO MAINTAIN A WATERTIGHT DETAIL INSIDE THE SCUPPER
2. METAL SUBSTRATE REQUIRE ROUGHENING/SANDING, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125. ALSO, IT MUST BE FREE OF ALL OIL AND RUST
3. WHEN GRAVEL/STONE BALLAST IS USED, A FILTER FABRIC MUST BE INSTALLED BETWEEN THE BALLAST AND STYROFOAM INSULATION
4. SPLICE TAPE SHOULD BE USED AT EXPOSED LAPS OF CONSECUTIVE PIECES OF FLEX-FLASH UN



**Monolithic  
Membrane  
6125-FR**  
ROOFING SYSTEMS

**AMERICAN HYDROTECH, INC.**

**THRU-WALL  
SCUPPER FLASHING**

SCALE: NONE  
DATE: 02/04/19

R-15A