



NOTES:

1. THE METAL SLEEVE SHOULD BE INSTALLED IN ONE PIECE OR COMPLETELY WELDED SHUT TO MAINTAIN A WATERTIGHT DETAIL INSIDE THE SCUPPER.
2. METAL SUBSTRATE REQUIRE ROUGHENING/SANDING, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125. ALSO, IT MUST BE FREE OF ALL OIL AND RUST
3. REFERENCE GUIDELINE DETAIL R-12 FOR ALTERNATE CORNER TRANSITION DETAILS AND R-13 FOR ALTERNATE TERMINATION DETAILS.
4. SPLICE TAPE SHOULD BE USED AT EXPOSED LAPS OF CONSECUTIVE PIECES OF FLEX-FLASH UN

	<p>Monolithic Membrane 6125-FR ROOFING SYSTEMS</p>
<p>AMERICAN HYDROTECH, INC.</p>	

<p>OVERFLOW SCUPPER FLASHING</p>	
<p>SCALE: NONE DATE: 02/04/19</p>	<p>R-15B</p>