

NOTES:

- AREA AROUND DRAIN SHOULD BE DEPRESSED/SUMPED TO PROMOTE POSITIVE WATER DRAINAGE.
- 2. REINFORCEMENT SHALL BE ONE SHEET OF FLEX-FLASH UN EXTENDING A MINIMUM OF 6" BEYOND THE DRAIN FLANGE ON ALL SIDES AND SECURED IN CLAMPING RING AT DRAIN.
- ALL DRAINS ARE REQUIRED TO HAVE FLASHING CLAMPING RING ASSEMBLIES. CONSULT SPECIFIC DRAIN MANUFACTURER FOR ADDL. ACCESSORIES (i.e., DEBRIS SCREENS, LOW-PROFILE DOMES, EXTENSIONS, ETC.)
- 4. APPROVED PROTECTION LAYER SHOULD NOT BE EXTENDED UNDER THE CLAMPING RING OF THE DRAIN. FLEX-FLASH F SHOULD STOP A MIN. OF 4" AWAY FROM THE DRAIN.



TYPICAL DRAIN DETAILS

SCALE: NONE DATE: 11/01/17

W-8A