



NOTES:

- WHEN FOUNDATION WALLS ARE CONSTRUCTED OF CONCRETE BLOCK (CMU), MM6125 MUST BE INSTALLED IN FABRIC REINFORCED MEMBRANE ASSEMBLY.
- 2. IT WILL TYPICALLY BE NECESSARY TO MECHANICALLY FASTEN THE HYDROFLEX PROTECTION MATERIALS TO PREVENT SEPARATION/SLIPPING.
- 3. THE TERMINATION DETAILS DEPICTED ARE SOME OF THE MORE COMMON ENCOUNTERED. FOR ALTERNATIVE TERMINATION OPTIONS, CONTACT HYDROTECH.
- 4. REGLETS CAN BE CAST/FORMED OR CUT INTO THE CONCRETE. REGLETS SHOULD BE MIN. 1/2" DEEP AND PROVIDE AN EASY TRANSITION FOR THE MEMBRANE FLASHING.



TYPICAL FOUNDATION WALL DETAILING AT GRADE

SCALE: NONE DATE: 11/01/17

W-12B