

## NOTES:

- 1. FIXED HEIGHT AND ADJUSTABLE PEDESTALS NECESSARY FOR AN OPEN-JOINT PAVER INSTALLATION CANNOT BE INSTALLED OVER GARDENDRAIN. THE GARDEN ROOF AND ULTIMATE ASSEMBLY INSTALLATIONS SHOULD BE DIVIDED.
- 2. PRECAST CURBING MAY REQUIRE STABILIZING AGAINST DIFFERENTIAL LOADING. (e.g. PINNING END-TO-END, MORTARING IN PLACE, ETC.). CONSULT PROJECT ENGINEER.
- 3. IF GARDENDRAIN ELEMENTS ARE INSTALLED UNDER HARDSCAPE AREAS THE CUPS MUST BE FILLED WITH LIGHTWEIGHT EXPANDED AGGREGATE. GARDENDRAIN MAY ALSO BE USED AS FORMS FOR SETTING CONCRETE FOOTINGS FOR CURBS, ETC.
- 4. REFER TO APPLICABLE MM 6125-FR ROOFING OR WATERPROOFING GUIDELINE DETAILS FOR PROPER MEMBRANE/FLASHING DETAILS AND ALTERNATIVES.



POSSIBLE TRANSITION OPTION
- PRECAST WALL UNITS (INTENSIVE APPLICATION DEPICTED)

SCALE: NONE DATE: 11/01/17

GA-5F