



NOTES:

1. APPLICATION OF APPROPRIATE HYDROSEAL PRIMER MUST PRECEDE APPLICATION OF HYDROSEAL FLASHING AND DECK MEMBRANES.
2. ALL HYDROSEAL FLEECE, INCLUDING OVERLAPS, MUST BE SET IN AND COVERED OVER WITH HYDROSEAL RESIN.
3. VARIOUS SURFACING OPTIONS ARE POSSIBLE. REFERENCE DETAILS HS-1A THROUGH HS-2B
4. HYDROSEAL SURFACINGS SHOULD BE HELD BACK 1" MIN. FROM THE GRAVEL STOP/ DRIP EDGE KICK-UP.
5. GRAVEL STOP/DRIP EDGE DECK FLANGE MUST BE SET IN A BED OF HYDROSEAL PASTE.
6. HYDROSEAL FLASHING EXPANSION STRIPS WITH DE-BONDING TAPE MUST BE INSTALLED OVER ALL JOINTS IN THE GRAVEL STOP/DRIP EDGE. REFERENCE DETAIL HS-5A FOR SIMILAR.



HydroSeal
Deck Membrane

AMERICAN HYDROTECH, INC.

**METAL GRAVEL STOP /
DRIP EDGE FLASHING**

**SCALE: NONE
DATE: 07/19**

HS-12