



NOTES:

1. WHEN POSSIBLE, MM6125 SHOULD BE APPLIED UNDER PENETRATION BASE PLATE.
2. PENETRATION SURFACE MUST BE CLEAN AND FREE OF ALL RUST AND OTHER CONTAMINANTS, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125.
3. IN COVERED/BURIED CONDITIONS, THE FLASHING DETAIL SHOULD EXTENDED AS HIGH AS POSSIBLE. FLASHING MUST BE TERMINATED AT OVERBURDEN LEVEL AND NO LESS THAN 8" ABOVE SUBSTRATE.
4. USE LARGEST SHEETS OF UNCURED NEOPRENE POSSIBLE. WHEN POSSIBLE, HOLES/SLITS SMALLER THAN THE PENETRATION SHOULD BE CUT IN THE CENTER OF THE SHEET OF NEOPRENE AND THE SHEET PULLED DOWN OVER THE PENETRATION.
5. CUT A SLIT OR "X" INTO THE NEOPRENE SHEET DIRECTLY OVER THE BOLT HEADS TO ALLOW EMBEDDING/FORMING TIGHTLY AROUND BOLT HEAD.

	<p>Monolithic Membrane 6125-FR ROOFING SYSTEMS</p>
<p>AMERICAN HYDROTECH, INC.</p>	

<p>ROUND SHAPE PENETRATION WITH BASE PLATE</p>	
<p>SCALE: NONE DATE: 12/01/17</p>	<p>R-10A</p>