

NOTES:

- PENETRATION SURFACE MUST BE CLEAN AND FREE OF ALL RUST AND OTHER CONTAMINANTS, IN ADDITION TO WIPING W/SURFACE CONDITIONER FOR PROPER ADHESION OF MM6125.
- IN COVERED/BURIED CONDITIONS, THE FLASHING DETAIL SHOULD EXTENDED AS HIGH AS
 POSSIBLE. FLASHING MUST BE TERMINATED AT OR ABOVE OVERBURDEN LEVEL AND NO
 LESS THAN 8" ABOVE SUBSTRATE.
- 3. USE LARGEST SHEETS OF UNCURED NEOPRENE POSSIBLE. WHEN POSSIBLE, HOLES/SLITS SMALLER THAN THE PENETRATION SHOULD BE CUT IN THE CENTER OF THE SHEET OF NEOPRENE AND THE SHEET PULLED DOWN OVER THE PENETRATION.
- 6. HYDROSEAL RESIN SHOULD BE APPLIED DIRECTLY OVER PRIMED MM6125



IRREGULAR SHAPE PENETRATIONS
CAST INTO DECK

SCALE: NONE DATE: 11/16/22

R-10C